

Table of Twin Double-Hung Window Sizes (Wood Market Sizes)

Scale 1/8" = 12" – 1:96

Window Dimension	41"	45"	53"	61"	69"	73"	77"	85"	93"
Minimum Rough Opening	40"	44"	52"	60"	68"	72"	76"	84"	92"
Unobstructed Glass (lower sash only)	13 9/16"	15 9/16"	19 9/16"	23 9/16"	27 9/16"	29 9/16"	31 9/16"	35 9/16"	39 9/16"

CUSTOM HEIGHTS – 30" to 76 3/4"	CUSTOM WIDTHS – 39" to 96"								
	41"	45"	53"	61"	69"	73"	77"	85"	93"
38 1/4"	16210	18210	20210	24210	28210	210210	30210	34210	38210
42 1/4"	1632	1832	2032	2432	2832	21032	3032	3432	3832
50 1/4"	16310	18310	20310	24310	28310	210310	30310	34310	38310
54 1/4"	1642	1842	2042	2442	2842	21042	3042	3442	3842
58 1/4"	1646	1846	2046	2446	2846	21046	3046	3446	3846
66 1/4"	1652	1852	2052	2452	2852	21052	3052	3452	3852
70 1/4"	1656	1856	2056	2456	2856	21056	3056	3456	3856
74 1/4"	16510	18510	20510	24510	28510	210510	30510	34510	38510
78 1/4"	1662	1862	2062	2462	2862	21062	3062	3462	3862

Custom-size windows are available in 1/4" increments.


Twin double-hung windows include a nailing flange and optional J-channel.

Windows have one continuous frame.

Grille pattern and number of lights varies with window size.

Custom Sizes & Specification Formulas

Twin Double-Hung Windows



Available in 1/4" increments between minimum and maximum widths and heights shown. Some restrictions apply.

	Clear Opening Width = (window width + 2) – 3.563" Height = (window height + 2) – 4.063"		Minimum R.O. Width = window width + 1/2" Height = window height + 1/2"
			Vent Opening Width = (window width + 2) – 3.563" Height = (window height + 2) – 4.063"

- "Window Dimension" always refers to inside frame to frame dimension.
- **"Minimum Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.**
- ♦ Meet or exceed clear opening area of 5.7 sq.ft., clear opening width of 20" and clear opening height of 24".

- **Clear Opening** formulas provide dimensions for determining area available for egress.
- **Vent Opening** formulas provide dimensions for determining area available for passage of air.
- **Minimum R.O.** (minimum rough opening) formulas provide minimum rough opening width and height dimensions.
- **Unobstr. Glass** (unobstructed glass) formulas provide dimensions for determining area available for passage of light.